

Control Charts

- Definition:
 - A statistical tool to determine if a process is in control.

Two Types of Control Charts

- Variable Control Charts
- Attribute Control Charts

Variable Control Charts

- Deal with items that can be measured .
- Examples
 - 1) Weight
 - 2) Height
 - 3) Speed
 - 4) Volume

Types of Variable Control Charts

- X-Bar chart
- R chart
- MA chart

Variable Control Charts

- X chart: deals with a average value in a process
- R chart: takes into count the range of the values
- MA chart: take into count the moving average of a process

Attribute Control Charts

- Control charts that factor in the quality attributes of a process to determine if the process is performing in or out of control.

Types of Attribute Control Charts

- P chart
- C Chart
- U Chart

Attribute Control Charts

- P Chart: a chart of the percent defective in each sample set.
- C chart: a chart of the number of defects per unit in each sample set.
- U chart: a chart of the average number of defects in each sample set.

Reasons for using Control Charts

- Improve productivity
- Make defects visible
- Determine what process adjustments need to be made
- Determine if process is “in” or “out of control”

Real World Use of Control Charts

- Example from “Managing Quality” by Foster.
 - The Sampson company develops special equipment for the United States Armed Forces. They need to use control charts to insure that they are producing a product that conforms to the proper specifications. Sampson needs to produce high tech and top of the line products, daily so they must have a process that is capable to reduce the risks of defects.

How Will Using Control Charts help your Company?

- Possible Goals when using Control Charts in your Company:
 - Line reengineering
 - Increased Employee motivation
 - Continually improve of your process
 - Increased profits
 - Zero defects

Control Chart Key Terms

- Out of Control: the process may not performing correctly
- In Control: the process may be performing correctly
- UCL: upper control limit
- LCL: lower control limit
- Average value: average

Process is OUT of control if:

- One or multiple points outside the control limits
- Eight points in a row above the average value
- Multiple points in a row near the control limits


Process is IN control if:

- The sample points fall between the control limits
- There are no major trends forming, i.e.. The points vary, both above and below the average value.

Calculating Major Lines in a Control Chart


- Average Value: take the average of the sample data
- UCL: Multiply the Standard deviation by three. Then add that value to the Average Value.
- LCL: Multiply the Standard deviation by three. Then subtract that value from the Average Value.

Examples of Control Charts



Examples of Control Charts


Process in Statistical Control



Control Charts

- The following control chart shows the improvement of a process. The standard deviation decreases as the process becomes more capable.

Example of Control Charts



How to Calculate the standard deviation

- P chart:
 - P= percent or rate
 - N= number of trails

$$\sigma = \sqrt{\frac{\bar{p}(1-\bar{p})}{N}}$$

How to Calculate the standard deviation

- C chart:
 - \bar{X} = the average

$$\sigma = \sqrt{\bar{X}}$$

How to Calculate the control limits

- X-bar Chart:

Lower Control Limit:

- $$\frac{\text{Mean} - 3 \cdot \sigma}{n(1/2)}$$

Center Line:

- Process mean

Upper Control Limit:

- $$\frac{\text{Mean} + 3 \cdot \sigma}{n(1/2)}$$

How to Calculate the control limits

- R chart:
 - Lower Control Limit:
 - $R\text{-Bar} - 3 \cdot d_3 \cdot \sigma$
 - Center Line:
 - R-Bar
 - Upper Control Limit:
 - $R\text{-Bar} + 3 \cdot d_3 \cdot \sigma$

Sample Size

- The sample set of data should be greater than 28.
- The data should have been collected uniformly
- The data should contain multiple capable points of data, or the information is incorrect.

Example

- First Step: Determine what type of data you are working with.
- Second Step: Determine what type of control chart to use with your data set.
- Third Step: Calculate the average and the control limits.

Example

- The following slides contain data and questions for your practice with control charts. Please take the process step by step and look back to previous slides for help.

Problem

- You have gathered a sample set of data for your company. The data is in the form of percents. Your company wants your recommendation, is the process in control.
- What type of control chart should you use? (Variable or Attribute)

Problem

- What type of specific control chart should you use with that type of sample set? (X-bar, R-chart, MA-chart, P-chart, R-chart, or U-chart)

Problem

- Now that you have determined the control chart to use, you have to calculate the average and standard deviation. Use the data on the following slide. Take notice to the amount of sample data. ($n > 28$)

Sample Data

<u>Day</u>	<u>Percent</u>	<u>Day</u>	<u>Percent</u>	
1		.056	15	.068
2		.078	16	.038
3		.064	17	.077
4		.023	18	.068
5		.067	19	.053
6		.078	20	.071
7		.067	21	.037
8		.045	22	.052
9		.034	23	.072
10		.045	24	.047
11		.062	25	.042
12		.051	26	.051
13		.070	27	.064
14		.039	28	.071

Example

- Now that you have calculated the three important lines for the control chart, plot the data and determine if the process is capable. (i.e. The data falls mostly inside the UCL, and the LCL)

Final Step

- Make a recommendation to your company.
 - The process is capable
 - The process is not capable
 - The following errors were found.
 - The process needs improvement
 - The variations are normal in the system and we must accept them.

Control Charts Review

- What have we learned?
 - Control Charts are a useful way to determine the capability of a process.
 - The different types of control charts.
 - How to calculate the control limits for a control chart.